

# Quick Guide Hybrid Mist

*For proper use of the Hybrid Mist, please read the Quick Guide before operation.*

**1:** Insert power plug into outlet.

**2:** Turn fireplace on using the **On** button.

**3:** Fill Demineralised Water - monitor **Tank indicator** to avoid overfilling.

Use ONLY Demineralised Water to ensure fireplace warranty.

**4:** Start the fireplace using the **Start button** (you will hear the pump start).

After pressing the **Start button**, it will take approximately 2 minutes for steam to emit.

**5:** Stop the fireplace by pressing the **Stop button** and wait for the pump to stop (approximately 2 minutes). Only then, turn off the fireplace using the **Off button**.

**6:** If the fireplace suddenly stops producing steam, it is recommended to follow step 5 and wait approximately 15 minutes before restarting the fireplace.

If you have any questions, please contact us at [info@decoflame.dk](mailto:info@decoflame.dk) or call +45 9630 4800.

Kind Regards

Technical Department, Decoflake ApS

## Video:

Refilling and Draining the Fireplace

